

# Retuning instructions for Panasonic FreeviewHD recorders



## Power up the Set top box

Press the Function Menu on the remote control

Select "Other" and press ok

Select "Set-up" and press ok

Select "Digital TV tuning" and press ok

Select "Auto Set up" and press ok to initiate a retune of the recorder