


Retuning instructions for MagicTV FreeviewHD receivers

Press **MAGICTV** button on your remote control to display the **Main Menu** screen on your television.

Use the arrow keys on the remote to move through the menu and the **OK** button to choose your option. Press **BACK** to return to the previous menu.



Select **Settings**.

Select Channel **Setup**.

Select **Auto Channel Scan**.



Select **Start Scan** and then press **OK** to confirm that you want to delete all current channels.

A yellow bar will represent the scanning process. Once scanning is complete your receiver will return to live television. Your television channel frequencies have now been retuned.