











SHARP

Freeview Channel Retuning

LC40LE820X / LC46LE820X / LC52LE820X LC60LE925X

1	Press the “DTV” button		
2	Press the “MENU” button to display the Menu		
3	Use the ◀▶ buttons to select “Setup” and press “ENTER”		
4	Use the ◀▶ buttons to select the “Spanner” icon (“View Setting” will be displayed) and press “ENTER”		
5	“Auto Installation” should be highlighted (If not then use the ▲▼ buttons to select “Auto installation”) Press “ENTER”		

<p>6</p>	<p>Skip step 6 and go to step 7 if the password request is not displayed.</p> <p>Enter your password (if you can't remember your password please refer to your operation manual).</p>	 <p>The screen shows 'Auto installation' at the top, followed by 'Please enter password'. Below this is a password input field consisting of four empty boxes, each with a horizontal line inside.</p>
<p>7</p>	<p>Use the ◀▶ buttons to select “Yes” Then press “ENTER”</p>	 <p>The screen displays 'Current country setting : New Zealand'. Below this is a note: '(If you wish to change the country setting, it is necessary to do a system reset through the Setup menu and choose: Reset.) Do you want to start the auto installation?'. At the bottom, there are two buttons: 'Yes' (circled in red) and 'No'.</p>
<p>8</p>	<p>Use the ▲▼ buttons to select the desired language listed on screen (eg English), and press “ENTER”</p>	 <p>The screen shows 'Display language settings'. There are three buttons: 'English' (circled in red), '中文', and 'عربي'.</p>
<p>9</p>	<p>Use the ◀▶ buttons to select “Digital Search” and press ENTER”</p>	 <p>The screen shows a single button labeled 'Digital Search' which is circled in red.</p>
<p>10</p>	<p>The TV will then display the channel search progress display (refer picture on right)</p>	 <p>The screen shows a progress display for channel search. At the top, it says 'TV [Setup ... View setting ... Auto installation ... Auto search]'. Below this is a table with three columns: '01 538.0', '02 570.0', and '03 634.0'. Each column has a blue progress bar below it.</p>
<p>11</p>	<p>When finished searching the TV should display a TV picture and the menu</p> <p>Press “Menu” to exit</p>	 <p>The screen shows a TV picture of a man in a suit. A menu is overlaid on the right side of the screen, listing options: 'Auto installation', 'Quick start', 'DivX(D) setup', 'Individual setting', 'Wall mount auto setup', 'Language', and 'Reset'. The 'Menu' button is highlighted.</p>